Signal	Plugin	Туре	Default
PC	Fetcher	UInt(32 bits)	
INSTRUCTION	Fetcher	Bits(32 bits)	
REGFILE_ADDR1	RegisterFile	UInt(5 bits)	I(9:5)
REGFILE_ADDR2	RegisterFile	UInt(5 bits)	I(14:10)
REGFILE_VAL1_ENABLE	RegisterFile	Bool()	False
REGFILE_VAL2_ENABLE	RegisterFile	Bool()	False
REGFILE_VAL1	RegisterFile	Bits(32 bits)	
REGFILE_VAL2	RegisterFile	Bits(32 bits)	
REGFILE_WRITE_ENABLE	RegisterFile	Bool()	False
REGFILE_WRITE_ADDR	RegisterFile	UInt(5 bits)	I(4:0)
REGFILE_WRITE_VAL	RegisterFile	Bits(32 bits)	
ALU_OP	IntAlu	AluOp	AluOp.add
ALU_OUT	IntAlu	Bits(32 bits)	

• ADD.W

ALU_OP	AluOp.add	
REGFILE_VAL1_ENABLE	True	
REGFILE_VAL2_ENABLE	True	
REGFILE_WRITE_ENABLE	True	